

Applying LIFELINE™ Over Existing Stains

We often get asked whether Perma-Chink's LIFELINE™ finishes can be applied over an existing stain. Since the answer to this question is not straight forward, we will look at the various types of stains individually. For the best look and performance of a LIFELINE™ finish, it is always best to remove any existing finish unless it is a LIFELINE™ finish. Even then, the existing LIFELINE™ finish needs to be in good condition before we recommend applying another coat on top of it.

Returning to the question, “can a LIFELINE™ finish be applied over other brands of existing finishes?” If the existing finish is water-based and there are no signs of grayed wood and the color on all the walls is uniform, the answer is typically yes. However, if the existing water-based finish contains additives, i.e., wax or oils, there may be a problem with the LIFELINE™ finish wetting the surface resulting in “fisheyes” in the film.

LIFELINE™ should never be applied over film-forming oil stains like Sikkens Cetol Log & Siding, Sashco's Transformation, or other alkyd oil-based stains. These types of finishes should always be removed before applying LIFELINE™. This also applies to penetrating oil stains like Woodguard, Outlast Q⁸ Log Oil, TWP, Olympic and others. Attempting to apply LIFELINE™ directly over an oil-based finish is risky. The last thing any of us want, is for you to be disappointed with the results.

The best way to remove an existing oil finish is with chemical stripping. The components in most chemical finish removers like our S-100™ and Striptlt® not only soften the finish but they also help remove any residual oil that may be present in the top layer of wood. Media blasting may remove the alkyd film or the oil-based pigments but does not remove any oils that have penetrated the wood. If LIFELINE™ is immediately applied to the blasted surface, there is a chance that the remaining oil residue will migrate to the surface creating adhesion problems or blisters in the

LIFELINE™ film. It is recommended that the surface, prior to staining, be cleaned with Cedar Wash™, rinsed well and pH checked.

Some Rules of Thumb:

1. If you do not know what specific finish is on your home, remove it.
2. If there are black streaks, mold spots or any other discolorations that you do not want to see through the final finish, clean the surface down to bare wood and remove them.
3. If there are signs of grayed wood or if the existing finish has areas that have peeled, clean the surface down to bare wood.
4. Never apply a LIFELINE™ finish over oil-based finishes.



YOUR WOOD CARE RESOURCE

Technical Tip